

## Power Winch

- Drill 3/8" hole through bracket mounted on the bottom of frame
- Set winch stand over top of holes
- Place 8 – 3/8" x 1 1/2" bolts through floor (8-310)
- Thread 8 – 3/8" large flange self-locking onto bolts (8-401NY)
- Tighten all bolts making sure stand is even with diamond plate seem in the middle
- Install nylon wear strip in the back of trailer
  - 7 wafer head tek screws (1024100TW)



3/8" x 1 1/2" Bolts